

Owner's Manual

Crane 350

Certificate no.CN.CE.0717 03/11





Contents

- 一、 **Products Range**
- 二、 **Specification**
- 三、 **Installation Instruction**
- 四、 **Crane 350-II 4x4 Wheel-Drive system**
- 五、 **Application**
- 六、 **Multi-Control Valves**
- 七、 **Service and Maintenance**
- 八、 **Fault Diagnosis and Rule Out**
- 九、 **Warranty Registration**

Thank you for buying Crane 350. We are continuously improving our quality, design and products range to satisfy customer demands.

一、 Products Range

Crane 350, with engine 7HP, mounted in the rear of ATVs or tractors, drives oil pump and outputs hydraulic oil. Working with seven pieces of cylinders and three pieces of rotators, crane 350 lifts, rotates and unloads etc.. There are moving parts, oil pump, multi-control valves, grapnel, supporting parts and automatic wheel-drive etc in crane..

Crane 350-I


Crane350-II (4X4 remote & electric control)

二、 Specification


| Items | Technical Data |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Gas Engine | 7HP , electric and pull start, adjustable engine speed:1400- 3800rpm |
| Oil Pump | 16Mpar, 4ML/R |
| Hydraulic System | Multi-Control Valves functions: A、 Arm access B、 Grappling movement: rotating, open and close , Lifting capacity of Max. reach: 200kg C、 Supporting legs adjustable in height of 535mm D、 Wheeldrive driven by two pieces of rotators E、 Boom rotation 45°left and right (safely) when the beam in the middle. rotating 90°left and right (maximum) |
| Working Temperature | 80°C~-30°C |
| Trailer Dimension | Trailer weight(kg): 260 Base between two supporting legs(m):1.6 Max. loading capacity(kg): 1500 Tire size: 22x11-10 |
| Crane Spec. | Dimension including trailer (LWHm):3.65×1.1×1.4 Max. lifting height(m):4.5 Arm length(m): 3.5 Gross weight(kg): Crane 350-I : 580 Crane 350- II: 630 |

三、 Installation Instruction(only for SKD loading)


1、 Fix on wheels




2、 Insert long tube




3、 Put on railings




4、 Fix front net & supporting legs




5、 Put on hook



6、 Fit with engine plate



7、 Fix on beam cylinders on legs and valves




8、 Connecting inlet pipe in valves to exit of oil pump. Connecting outlet pipe to fuel tank



四、Crane 350-II 4x4 Wheel-Drive System

● Wheel-Drive Installation

9、 Open cap(1). 10、 Four pcs of oil pipes go through (2) to (3). Equip solenoid valve and control box like (4). 11、 Connect plugs like (5,6,7)



12、 Tighten four pcs of oil pipes. Pipe a and c shall be the upper. 13、 Tighten inlet and outlet oil pipes. Connect power.



14、 When the battery voltage is low, use the external power cord into the above diagram, A termination to external 12V battery

● Please read the following before applying wheel-drive system

15、 Start the engine, the speed is over 70%

- 16、 Click No. 3 on the remote control button, so that driving wheel and tire bonding
- 17、 When the driving wheel down to tire tread , click No. 5 or 6 button , so that driving wheel stop declining
- 18、 To the end of work for wheel-drive system, click No.4 button to driving wheel up to the highest point, press No. 5 or 6 button to stop
- 19、 To ensure sufficient power in engine battery and remote control battery, no battery power will affect work of wheel-drive system



 When Use the system, non-stand in front and rear of crane

五、 Application

- Please check the following before applying for crane. :
 - 1、 Connecting axles and tablets are in proper positions, nuts are tightened.
 - 2、 Fill anti-wear hydraulic oil to two- thirds of oil level in fuel tank. (In cold area, hydraulic oil shall be cold temperature resistant)
 - 3、 Fill oil in the middle of dipstick. Fill gas in engine, do not overflow.
 - 4、 Lay out hoses in proper position, screw up nuts
- Engine starting: (See engine instruction manual)。
- General information about application.

Drive smoothly and reduce loading until you can completely control cranes.

Raising of heavy weights far from side of trailers that will increase pressure to cranes, it shortens the life of trailer significantly.

The ATV's rear wheels shall be raised from ground with supporting legs during loading in order to reduce weight on ATV's ball hitch.

Pressure of oil pump in delivery is about 12Mpar-14Mpar, Max. working pressure is 16Mpar. It's not recommended to adjust pressure for a strong turn.

- Warranty

The warranty's period and coverage is set by importers, distributors and dealerships.

Warranty terms vary from places due to geographical settings.

Scandi factory does not respond for end users, end customers and retailer's warranty claim.

六、 Multi-Control Valves

Crane hydraulic system consists of oil pump, multi-control valve、 relief valve、 balance valve, oscillating cylinder, travel motor, grapple rotator and seven pieces of linear cylinders. Multi-control valves arrays as following:



- 1、 Pressure of relief valve is 10Mpar~12Mpar. Please adjust relief valve or increase engine speed for compression to lift heavier weights.
Relief valve is in right sight of multi-control valve. Take away the cap, there is A-folt bolt. Clockwise is adding to pressure, Anticlockwise is reducing pressure.

- 2、 In initial starting or in the long stopping status, there is air in hydraulic system, valves can not work accordingly. It will work well for a while when air is out.
- 3、 Operation handles are automatic reset.

七、 Service and Maintenance

| Parts | Lubrication material | Period | Picture |
|------------------------------------------|-------------------------|-------------------------|---------------------------------------------------------------------------------------|
| 10 pcs of axle in beam | Lithium Grease | Every 50 working hours |  |
| 6 pcs of couplings in grapnel | Lithium Grease | Every 30 working hours |  |
| oscillating cylinder/ rack and pinion | Lubricants No. 20 (1kg) | Every 100 working hours |  |

| | | | |
|----------------------------------------------------|------------------------------|-----------------|-------------------------------------------------------------------------------------|
| Running Bearings/5 pcs of bearings in tire's shaft | Special Lithium-based grease | Every 12 months |  |
| Running Bearings/ in trailer frame | Special Lithium-based grease | Every 12 months |  |



NYHET – NETTHANDEL
1000 produkter
wee.no

The advertisement features a central orange background with the text 'NYHET – NETTHANDEL', '1000 produkter', and 'wee.no'. Surrounding the text are eight small images of various pieces of equipment: a red excavator bucket, a red excavator arm, a grey generator, a blue and white storage shed, a red tractor, a white storage shed, a yellow generator, a yellow tractor, a yellow loader, and a red tractor.

八、Fault Diagnosis and Rule Out

| Phenomenon | Causes | Solutions |
|---------------------------------------|--------------------------------------------------------------|----------------------------------------------------------|
| Oil pump voice anomaly | Air in system | Tighten connecting nuts of hoses |
| Multi-control valves don't work | Air in cylinder | Move valves slightly to let air out |
| Boom lifts and declines automatically | Air in system | Tighten seal nuts in hoses |
| Crane can't lift weights | Too low pressure in relief valves | Regulating relief valves |
| Lift arm moves unstably | Short of hydraulic oil | Add more hydraulic oil |
| Engine flameout | Logs overweight | Regulate engine speed or Lower pressure of relief valves |
| Interface leakage | Arc tooth seal deformed by temperature or plane seal damaged | Tighten nut or change plane seals |

九、Warranty Registration

The owner must produce this card whenever a claim made:

| |
|---------------------------|
| Engine no.: |
| Multi-control valves no.: |
| Model no.: |
| Color: |
| Date of Purchase: |
| Dealer's name: |
| Dealer's area: |
| Your name: |
| |

